# EPOS SDW 30/60 Battery Replacement

# Disassembling the rechargeable battery pack

## Required material

- new Battery pack for SDW 30 HS | SDW 60 HS ID No. AHB732038TPCT
- Tool such as a small plastic rod and paper clip for SDW 60 HS

## Opening the battery compartment



#### CAUTION!

### Damage to the product due to improper handling!

The wires can be kinked or damaged if you open the battery compartment too jerkily.


Carefully open the battery compartment.

#### SDW 30 HS



 Slide one finger into the small recess on the side support.

#### SDW 60 HS



 Use a paper clip or similar tool to press the unlock button and turn the cover a bit.

The battery compartment lifts a bit

Gently remove the battery compartment cover.

# EPOS SDW 30/60 Battery Replacement

## Removing the rechargeable battery

### SDW 30 HS



SDW 60 HS



Use a plastic tool (e.g. small plastic lifting rod) to lift the rechargeable battery. Please note, that the battery is attached with an adhesive.


SDW 30 HS



Remove the rechargeable battery.

Carefully loosen the connector plug.

SDW 60 HS



# EPOS SDW 30/60 Battery Replacement

## Assembling the new battery pack

SDW 30 HS



SDW 60 HS



- Rotate the battery so that the marking signs are visible at the top.
- > Insert the connector plug of the new rechargeable battery into the connection socket. Observe correct orientation of the connector plug.
- Press on the plastic parts to securely lock the connector plug.

# EPOS SDW 30/60 Battery Replacement

### SDW 30 HS



SDW 60 HS



- Insert the battery and assure that the marking signs are visible at the top. Place the battery centered to secure an air gap around it.
- Make sure that the wires are aligned and not crossing over each other. Gently press down the three wires and the battery.
- > Slide in the battery compartment cover.

### SDW 30 HS



Start attaching the lower side (as shown) and then push the other side down. Finally, push the sides into place.

SDW 60 HS




 Close the battery compartment and turn the lid clockwise. You hear a click.

# EPOS SDW 30/60 Battery Replacement

# Testing the battery and final adjustments

Test the function of the headset: Press the Hook button to switch on the headset. The LED lights up blue.



- Charge the battery for at least 20 minutes before using the headset. See User Guide for further information.
- Switch off the headset before sending it to the customer. Press and hold the Hook button for 5 seconds. The headset switches off. The Headset LED flashes red 3 times and turns off.

